

Surgical hand disinfection

Standard rubbing method as per EN 12791

Surgical hand disinfection is performed with visually clean and dry hands. Hand cleaning is necessary prior to the first surgical hand disinfection of the day or if the hands are visibly dirty.



Dispense the hand disinfectant decosept® into the hollow dry hand. Depress lever with elbow.



First disinfect hands and forearms up to the elbow with decosept®. Hands and forearms must be kept wet with hand disinfectant according to the manufacturer's instructions for the duration of the declared contact time.



In the last step disinfect the hands, observing the method "Hygienic hand disinfection according to EN 1500". Ensure hands must remain moist throughout the entire application time.



Hands shall be air dry before putting on surgical gloves. Keep hands above elbow level.